



SMARTER BUSINESS COMMUNICATIONS

[support@ipitomy.com](mailto:support@ipitomy.com) | 941.306.2200

---

### Xorcom Astribank Setup

1. In order to setup an Astribank you have to first plug it in to an available USB port on your system. Note which USB port you use. Once configured, the Xorcom will have to be connected to the same USB.
2. Log into the PBX
3. Go to Providers=>Hardware Providers. The Astribank should be listed under the USB devices area.
4. The PBX will detect the model of Astribank, ensure the correct type is selected and then hit the set button, then Apply Changes.
5. Make a range of extensions to associate with the FXS ports. When you add the range, make sure you select Astribank as the device type
6. Save and Apply changes
7. Perform Auto Discovery
8. Under Advanced Filter Settings click None then click the Refresh button
9. Set the appropriate Astribank ports to the corresponding extensions
10. Click the Assign button
11. Go to Providers=>Hardware Providers, scroll to the bottom of the page and click the button for Restart USB Devices and PBX Services
12. At this point you can connect your analog phones and make calls