

Broadvox Configuration Guide

IPitomy GUI follows:

SIP Provider	
Name:	<input type="text" value="broadvox"/>
User Type:	<input type="text" value="friend"/>
DTMF Mode:	<input type="text" value="rfc2833"/>
Host:	<input type="text" value="209.249.3.59"/>
Register:	<input type="radio"/> Yes <input checked="" type="radio"/> No <input type="radio"/> Custom <input type="text"/>
Authorization:	<input type="radio"/> Yes <input checked="" type="radio"/> No <input type="radio"/> Custom <input type="text"/>
From Domain:	<input type="radio"/> Default <input checked="" type="radio"/> Custom <input type="text" value="dfwnx01ga1.psv.broadvox"/>
Outbound Proxy:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="text"/>
Username:	<input type="text" value="9095272621"/>
Secret:	<input type="text"/>
Inbound Caller ID:	<input type="text"/>
Outbound Caller ID Name:	<input type="text"/>
Outbound Caller ID Number:	<input type="text"/>
Call Limit:	<input type="text" value="1"/>
Qualify:	<input type="text" value="8000"/>